










American **Suessen** Corporation

FESTO / Neuenhauser

 <p>2883016 Push-in Fitting FESTO QSM-M7-6-I</p>	 <p>2883017 Mounting Kit FESTO ZVB-8-14/18</p>	 <p>2883018 Silencer FESTO UC-M7</p>	<p>2883042 Bellows Suction Cups FESTO VASB-55-1/4-NBR</p>	 <p>2883044 Bellows Suction Cup FESTO VASB-55-1/4-PUR Neu: 819364-05</p>
<p>2883045 Vacuum Switch FESTO VPEV-1/8 Neu: 810437-01</p>	<p>2883046 Rod End Female Festo 9254 Neu: 818987.006</p>	<p>2883047 Flow Control Valve FESTO GRLA 3/8-QS-8 RS-B Neu:</p>	<p>2883048 Flow Control Valve FESTO GRLA-1/8-QS-6-RS-D Neu: 819380-03</p>	<p>2883049 Flow Control Valve FESTO GRLA-1/4-QS-8-RS-B Neu: 819380-06</p>
 <p>2883050 Connector FESTO Straight R 1/4 x M8 Neu: 819341-05</p>	 <p>2883051 Connector FESTO Straight R 3/8 x M10 Neu: 819341-08</p>	<p>2883052 Connector FESTO Straight R 1/4 x M6 Neu: 819341-05</p>	<p>2883053 Connector FESTO Straight R 1/8 x M6 Neu: 819341-02</p>	 <p>2883054 Connector FESTO Straight R 3/8 x M8 Neu: 819341-07</p>
<p>2883055 Connector FESTO <u>Short Elbow R 1/8 x M6</u> Neu: 819362-02</p>	 <p>2883056 Connector FESTO <u>Long Elbow R 1/8 x M6</u> Neu: 819362-02</p>	 <p>2883057 Connector FESTO <u>Short Elbow R 1/4 x M8</u> Neu: 819362-05</p>	<p>2883058 Connector FESTO Elbow G 3/8 x M8 Neu: 819362-07</p>	<p>2883059 Connector FESTO <u>Short Elbow R 1/4 x M6</u> Neu: 819362-04</p>
<p>2883060 Connector FESTO Elbow Double R 3/8 x M8 Neu: 819547-07</p>	<p>2883061 Connector FESTO Elbow Double R 3/8 x M10 Neu: 819547-08</p>	<p>2883062 Connector FESTO Elbow Triple R 3/8 x M10 Neu: 819345-08</p>	<p>2883063 Connector FESTO Elbow Triple R 1/4 x M6 Neu: 819345-04</p>	 <p>2883064 Connector FESTO Y Type R 1/4 x M8 Neu: 819550-05</p>

FESTO / Neuenhauser

 <p>2883065 Connector FESTO T Type R 1/8 x M6 Neu: 819536-02</p>	<p>2883066 Connector FESTO T Branch (Female) R 1/8 x M5 Neu: 819368-02</p>	<p>2883067 Connector FESTO T Branch (Female) R 1/8 x M8 Neu: 819368-07</p>	 <p>2883070 Coil w/ Connector FESTO MSFG 24/42 50/60 Neu: 819343-01</p>	 <p>2883071 Connector FESTO Straight G 1/4 x xM10 Neu:</p>
 <p>2883072 Flow Control Valve FESTO GR QS 3/8</p>	<p>2883073 Cylinder FESTO ADVUL-40-15-PA Neu: 819754-040-015</p>	 <p>2030237 Socket Head Screw M6—1.00 x 20 Neu: 120001-037</p>	 <p>2110067 Nut Machine Screw Hex M6—1.00 Neu: 120010-005</p>	<p>2883074 Cylinder FESTO DNGU-32-250-PPV-A Neu: 819373-09</p>
<p>2883075 Cylinder FESTO DNGU-50-100-PPV-A Neu: 819373-09</p>	<p>2883076 Guide Unit FESTO FENG-32-80 Neu: 819374-09</p>	<p>2883077 Guide Unit FESTO FENG-32-250 Neu: 700540-01</p>	<p>2883078 Cylinder FESTO DNG-32-80-PPV-A Neu: 819373-04</p>	<p>2883079 Proximity Sensor FESTO SMT0-1-PS-K-LED-24-C Neu: 810433-01</p>
<p>2883080 Mounting Kit FESTO SMBU-1-B Neu: 819375-01</p>	<p>2883081 Cylinder FESTO DSNU-25-100-PPV-A Neu: 860109-01</p>	<p>2883082 Cylinder FESTO DSNU-25-50-PPV-A</p>	 <p>2883083 Proximity Sensor FESTO CRSMEO-4-K-LED-24 Neu: 860102-01</p>	<p>2883084 Proximity Sensor FESTO SMT-8-PS-K-LED-24-B Neu: 810436-07</p>
<p>2883085 Tubing (50 Meters) FESTO PUN 6 x 1-DUO-SI</p>	<p>2883086 Tubing (50 Meters) FESTO PUN 8 x 1.25-SI</p>	<p>2883087 Tubing (50 Meters) FESTO PUN 10 x 1.25-SI</p>	<p>2883088 Cable Connector FESTO KMV-1-24DC-5-LED</p>	<p>2883089 Solenoid FESTO MVH-5/3E-1/4-B</p>

FESTO / Neuenhauser

<p>2883090 Silencer FESTO U-1/4/B</p>	<p>2883091 Cable Connector FESTO KME-1-24DC-2.5-LED</p>	<p>2883092 Silencer FESTO U-1/8/B</p>	<p>2883093 Subbase FESTO AU-ME-1/8</p>	<p>2883094 Solenoid FESTO JMEH-5/2-1/8-P-B</p>
<p>2883095 Adaptor FESTO AD-M10 x 1.25-1/4</p>	<p>2883096 Valve FESTO HGL-3/8-B</p>	<p>2883097 Connector FESTO N-3/8-P-13-M5</p>	<p>2883098 Silencer FESTO U-3/8-B</p>	<p>2883099 Solenoid Valve FESTO MFH-3-1/8</p>
<p>2883100 Contactor Block FESTO PRS-ME-1/8-4</p>	<p>2883101 Vacuum Generator FESTO VAD-ME-3/8</p>	<p>2883102 Pressure Switch FESTO PEV-1/4-B</p>	<p>2883103 Elbow Fitting FESTO LJK-3/8</p>	<p>2883104 Filter Regulator FESTO LFR-3/8-D-MIDI-A</p>
<p>2883105 Basic Valve FESTO LR-D-MIDI</p>	<p>2883106 Mounting Kit FESTO SMBR-25</p>	<p>2883108 Rod Clevis FESTO SG-M10 x 1.25</p>	<p>2883109 Angle Gripper FESTO HGW-32-A</p>	<p>2883110 Solenoid Valve FESTO JMFH-5-1/8-B</p>
<p>2883111 Solenoid Valve FESTO MFHE-3-3/8</p>	<p>2883112 Linear Drive FESTO DGP-63-600-PPV-A-B</p>	<p>2883113 Proximity Sensor FESTO SME-8-S-LED-24</p>	 <p>2883114 Valve FESTO HGL-3/8-NPT</p>	 <p>2883115 Valve FESTO HGL-1/8-B</p>

FESTO / Neuenhauser

<p>2883116 Pressure Gauge FESTO MA-50-16-1/4-EN</p>	 <p>2883117 Silencer FESTO U-M5</p>	<p>2883118 Cylinder FESTO ADVULQ-40-150-A-P- A-S20 w/ ATEX</p>	<p>2883119 Cylinder FESTO ADVULQ-40-165-A-P- A-S20 w/ ATEX Neu: 819365-111</p>	<p>2883120 Cylinder FESTO ADVULQ-40-150-A-P- A-S20</p>
<p>2883121 Cylinder FESTO ADVULQ-40-165-A-P- A-S20</p>	<p>2883122 Subbase FESTO PBL-3/8-D-MIDI-L</p>	<p>2883123 Subbase FESTO PBL-3/8-D-MIDI-R</p>	 <p>2883124 Swivel Connector FESTO LCK-1/4-PK-9</p>	<p>2883125 Connector FESTO Straight QS-1/8-8</p>
<p>2883126 Connector FESTO Elbow QSL-1/8-8</p>	 <p>2883127 Swivel Connector FESTO LCK-1/8-PK-6</p>	 <p>2850448 Solenoid FESTO MFH-5-1/8</p>	<p>2882192 Valve FESTO LFR-D-MIDI-A</p>	<p>2882194 Linear Drive FESTO DGO-25-500-PPV-A-B</p>
<p>2882290 Cylinder FESTO DSW-32-50-PPV-A-B</p>	<p>2882291 Cylinder FESTO DSW-32-80-PPV-A-B</p>	<p>2882292 Solenoid FESTO MFH-5/3-G-1-C</p>	<p>2882293 Hollow Bolt FESTO VT-1/4-PRS</p>	<p>2882294 Solenoid FESTO MFH-5-1/4</p>
<p>2882295 Rotary Actuator FESTO DSR-32-180-P</p>	<p>2882296 Solenoid FESTO MFHE-3-1/2</p>	<p>2882297 Flow Control Valve FESTO GRLA-M5-PK-4-B</p>	<p>2882298 Solenoid FESTO MFH-5/3G-1/4B</p>	<p>2882299 Flow Control Valve FESTO GRLA-1/8-RS-B</p>

FESTO / Neuenhauser

2882300 Flow Control Valve FESTO GRLA-1/8-PK-3-B	2882301 Solenoid FESTO MFH-1/8-B	2882302 Sound Absorber FESTO U-1/8	2882303 Bellows Suction Cup FESTO VASB-75-1/4-NBR	2882304 Cylinder FESTO DNG-32-100- PPV-A